

NO-SAG #1

DESCRIPTION

NO-SAG #1 is a dry powder designed to thicken ELAST-O-COAT while allowing it to remain flexible. The thickened epoxy is used to fill control joints where movement is expected. It is typically applied with a trowel or caulking gun.

TYPICAL USES

NO-SAG #1 is required when applying ELAST-O-COAT with fiberglass tape over seams on floor applications over plywood. NO-SAG #1 can also be used to prevent ELAST-O-COAT from seeping into control joints.

MIX FOR CRACK FILLING (moving)

1 quart of Hardener (A)

½ gallon of Resin (B)

1 gallon NO-SAG #1

For larger areas, double the above recommendations.

APPLICATION METHOD

The best method of adding this product to epoxy is to add the epoxy resin to the hardener, stir until blended well, then add the NO-SAG #1 to the mixing liquids. Adjust amount to increase viscosity to the consistency desired. One gallon of NO-SAG #1 weighs approximately 1 lb.

LIMITATIONS

Minimum temperature of 55°F is required during curing period. This product is not designed to be used with DUR-A-GLAZE #4.

PACKAGING

NO-SAG #1 is packaged in 25 lb bags.

CAUTION

As with all fine powders and dust, avoid inhalation of particles. Wear gloves because the fine powder will absorb skin moisture. Wash hands after contact. **Follow the Hazardous Materials Identification System labeling guide for proper personal protective equipment to use when handling this product. Use only as directed. KEEP OUT OF REACH OF CHILDREN.**

Before using any DUR-A-FLEX, Inc. product, be sure the Material Safety Data Sheet is read and understood.