



$D = W/2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF EXPANSION JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
 860-528-9838

TITLE **HYBRI-FLEX EQ**
 EXPANSION JOINT WITH REINFORCEMENT DETAIL

DATE 4/13

SCALE AS NOTED

DWG NO. HF-3A

PROJECT